

HYPE™

# SMART WATCH



Operation Manual

Thank you for purchasing the Hype Smart Watch. Please read all instructions carefully before using and retain this manual for future use and reference.

## **PACKAGE CONTENTS**

- Smart Watch
- USB Charging Cable
- Operation Manual

## **KEY FEATURES**

- Play music wirelessly
- Media shortcut controls
- Rechargeable lithium-ion battery
- Built-in microphone and speaker

## **SAFETY INSTRUCTIONS**

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not puncture or harm the exterior surface of the product in any way.

Keep the unit free from dust, lint, etc.

Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device.

This product is not a toy. Keep out of reach of children.

Do not expose batteries, battery pack, or batteries to be installed to excessive heat, such as direct sunlight, or open flame.

# SMART WATCH FEATURES



## PRODUCT FEATURES

1. Touch Screen
2. Power / Home Button
3. Adjustable Silicone Wrist Strap
4. Speaker
5. Micro USB Charging Port
6. Microphone
7. Confirm / Answer Call
8. Dial / Scroll / Flip
9. Return / End Call

## HOME SCREEN

Once your smart watch turns on, it will show you the below home screen.



1. Bluetooth Symbol - Indicates watch is paired to a device.
2. Battery - Indicates remaining battery life on the Smart Watch.
3. Time - Shows current time
4. Date - Shows today's date
5. Menu - Navigates to the Main Menu
6. Volume - Volume Adjustment for Speaker
7. Bluetooth - Setup Screen for Bluetooth Pairing

## STANDBY MODE



Press the Power Button once to put your Smart Watch in standby mode. The screen will go dark.

Press the Power Button a second time to display your watch and the time.

Press and hold the Power Button to unlock your Smart Watch and return to your Home Screen.

# COMPATIBILITY

Please note, some features of your smart watch are only available to specific devices.

At the top of each section of the manual, compatibility is shown using the two icons below.



Only available for Android devices.



Available for Android and Apple devices.



Only available for Apple devices.

# BLUETOOTH PAIRING



Make sure your Smart Watch is turned on and fully charged.  
Make sure Bluetooth is enabled on your smart phone or tablet and your device is discoverable.



NOTE: Android users should download and run the "Fundo Companion" App prior to pairing with Bluetooth. See "Settings / QR Code" for installation details before pairing.



Press the Menu Icon on your home screen to enter the main menu.




Press the Bluetooth Icon on your home screen to enter Bluetooth settings screen.



Press the word "Power" on your touch screen and ensure the green icon on the right reads "On."




This will turn on your watch's Bluetooth.



On

Press the word "Visibility" on your touch screen and ensure the green icon on the right reads "On."

This will let your smart phone or tablet find your watch..



**HY-WTCH-BT**



Press the phrase "My Name" on your touch screen to see the first few letters of your watch's pairing name.

In the Bluetooth settings for your smart phone or tablet, search for nearby devices and find your watch.



It should appear as "HY-WTCH-BT"  
Select it to begin pairing.




On your smart watch, press "My device," "Search new devices" and select your device on the next screen.



Your smart watch will send a pairing code to your phone. Make sure the codes match on your smart watch and on your device screen.



Press "Pair" from your smart phone or tablet.



Press the "Confirm" button on the outer frame of your smart watch.



NOTE: For Android users, after pairing with Bluetooth, your smart watch will ask you to sync date and time.



Press the "Confirm" button on your watch frame to finish the sync process.

Your watch should confirm with "Success"



Pairing is now complete. If you are unsuccessful, press the "Return" key on the frame of your smart watch to repeat the pairing process.

To restart the pairing process, you will first need to turn off "Visibility" and turn off Bluetooth "Power" first. Then turn Bluetooth off on your device and begin from the first step of this section.

To switch to another smart phone or tablet, return to the "My device" page and select your tablet or smart phone from that page. You may need to disconnect previously paired devices before attempting to switch between paired devices.

# BT NOTICE



Press the BT notice Icon on your home screen to set and customize your notifications.



BT notice  
"Please  
install "BT  
Notice"" app  
in remote device

This App can only be used on smart watches paired with Android devices.

Before using, please download the "Fundo Companion" App. See "Settings / QR Code" for installation details

Push notifications set on your phone will appear as a short preview on your smart watch. An incoming message is shown as an example below.

Scroll down on your touch screen to see time and date of notification.  
Press the "Scroll" button on your watch frame to view additional notifications if you have more than one.



1. Notification #/ Total # of Notifications
2. Messaging App Icon
3. Messaging App Name
4. Contact Name

5. Message Preview
6. Notification Date
7. Notification Time

BT Notice will send push notifications to your smart watch from your Android phone from all compatible Apps on your Android that are set for push notifications.

Some compatible BT notice Apps are listed below:



SMS Messaging



What's App



Message +



Gmail

NOTE: Open source App compatibility with "BT notice" may vary based on software design and are subject to change without notice.

Hype™ is not responsible for software updates and software compatibility made by third party software developers on the Android platform or on the Play Store.



When you are reading your Notifications, press the "Return" button on your watch frame to return to your App menu screen.

# MESSAGES



Press the Messages Icon on your home screen to view sent and received messages.



BT notice  
"Please  
install "BT  
Notice" app  
in remote device


This App can only be used on smart watches paired with Android devices.

Before using, please download the "Fundo Companion" App. See "Settings / QR Code" for installation details

Your smart watch will sync with SMS Messaging on our phone to show your Inbox and Sent Messages.


Select the list you would like to access. Scroll down to access the full list. Select an entry on the list to see message details and message body.





The date and time of the message will appear at the top of the message body.

Scroll down to read the full message.



When you're done reading your messages, press the "Return" button to return to your Inbox or Sent Messages folder.

Press the "Return" button again to return to your messaging folder.



When you are reading your Messages, press the "Return" button on your watch frame to return to your App menu screen.

# VOLUME



Press the Volume Icon on your home screen to adjust alarm and music volume.

On the next screen, use the “-” or “+” buttons on your touch screen to adjust volume.



These buttons will control the volume of your music if you are connected to your smart watch. See “Bluetooth Music” section for more information.



BT Music

If you are not connected to “Bluetooth Music,” these buttons will adjust the volume of your notification noises and watch interactions.

If you do not press the “+” or “-” button on this screen for 3 seconds, the smart watch will automatically return to your home screen.

# MENU LIST



Press the Menu Icon on your home screen to see your available smart watch Apps.

Your smart watch will begin displaying available Apps.



If you are looking for a specific App but do not see it on your screen, press the "Scroll" button on your watch frame to scroll to the next page.

You can also scroll through your Apps by swiping left or right on your touch screen.



At any time while using Apps, press the "Return" key to return to the previous page.

Eventually, you will be taken back to the home page.

# SETTINGS



Press the Settings Icon on your home screen to adjust settings on your smart watch.

## SETTINGS QR code



"Quick Response Code" will display the Setup QR code.



Please note, this QR code is to be used for quick setup and pairing of your smart watch with your smart phone or tablet.

This feature is only available for Android devices.


Using your Android smart phone, scan the QR code from your smart watch, open and install the "Fundo Companion" App in order to quick sync your messages, push notifications, and date and time.

Install the downloaded App and have it ready and running on your Android device before Bluetooth pairing.






"Time and date" will allow you to set the time and date.



Press the "Return" key on your watch frame to return to the previous page.




Select "Set home city" to view the list of cities.

Scroll through this list by swiping your finger upwards on your watch touch screen. Find your desired city, and press its name on the touch screen of your watch.


In the example below, "New York" is chosen.

Select "Date settings" to put in the current date.



A dial will appear to let you indicate the current date. Press the field you wish to edit and then press the plus or minus symbols to increase or decrease the number.


Press "OK" to confirm the date, press "Back" to exit without saving the date.



A dial will appear to let you indicate your alarm time. Press the field you wish to edit and then press the plus or minus symbols to increase or decrease the number.

Press "OK" to confirm the time, press "Back" to exit without saving the time.



Select "Set format" to set your digital clock to show time in the standard 12-hour format, or the 24-hour military format.



Press the left or right arrows to cycle through "12" or "24." Press the "Return" key on your watch frame to confirm your selection.

If you select the 24-hour time format, make sure your time is input in your watch as such under the "Set time/date" section.

Select "Update with time zone" to turn the automatic update during Daylight Savings Time on or off.



When Update options are set and shown correctly, press the "Return" key on your watch frame to confirm the information.

Keep pressing the "Return" key until you return to your "Settings" main screen.


# SETTINGS Language



Select “Language” to choose the language shown on your smart watch. The default setting is “English.”

Scroll through this list by swiping your finger upwards on your watch touch screen. Find your desired language, and press its name on the touch screen of your watch.

In the example below, “English” is chosen.



When your selection is confirmed, your watch will show you “Done” and take you back to “Settings” main screen.

# SETTINGS Display




Select "Display" to adjust your preferences for wallpaper and automatic Standby mode.



Select "Wallpaper" to view the background of the home screen. Please note, selection of available pre-programmed wallpapers may vary depending on Smart Watch model. The default Image 1 will always be available as a preset. It will be a basic black wallpaper.



Press the confirm key on your smart watch to confirm the selection, press the back key on your smart watch to go back to the display menu.



Select "Enter standby" to set the timer for standby mode. Choose between Off, 15 secs, 30 secs, 1 min and 5 min. You may need to scroll on your touch screen to see all options.


Keep pressing the "Return" key until you return to your App menu.



"Common settings" will allow you to choose your unlock screen clock type, enable the motion sensor features and change the LCD backlight settings.



"Unlocking type selection" will allow you to select the type of clock you want your watch to display when your smart watch is in Standby Mode.



The default setting is "Digital Clock 1". When selecting the other clocks you will not have access to the same app shortcuts that "Digital Clock 1" has.

After you have made your selection, your smart watch will show you that your selection is "Done."

Unlocking type s...

Analog Clock 1

Analog Clock 2

Digital Clock 1

Digital Clock 2



Unlocking type s...

Analog Clock 1

Analog Clock 2

Digital Clock 1

Digital Clock 2



Unlocking type s...

Analog Clock 1

Analog Clock 2

Digital Clock 1

Digital Clock 2




Unlocking type s...

Analog Clock 1


Analog Clock 2

Digital Clock 1


Digital Clock 2



"Motion sensors" will allow you to enable different motions to mute the watch when ringing.



When Motion sensor is off, the other options will not display.



Use the left and right arrow keys to turn the motion sensor on or off. More options will display below.



Use the left and right arrow keys to turn "Flip to mute incoming call" on or off. This function requires you to flip the watch upside down in order to mute an incoming call.

Scroll down on the touch screen of the watch to access the next option.


Use the left and right arrow keys to turn "Flip to mute alarm" on or off. This function requires you to flip the watch upside down in order to mute a ringing alarm.



When you have finished setting all desired motion sensors, press the "Return" key on your smart watch frame to return to the "Common settings" menu screen.




"Misc. settings" will allow you to adjust your preferences for the LCD backlight



Select "LCD backlight" to adjust screen brightness, and the duration of the brightness.

Use the sliding bars to set your desired preferences.




When display preferences are set, press the "Return" key on your watch frame to confirm the information.

Keep pressing the "Return" key until you return to your App menu.



"Restore settings" will allow you to reset all settings on your phone and clear all Bluetooth devices and personal information. It is best to use this feature if you no longer want your smart watch.



Press the "Confirm" button on your watch frame to begin the restore process.

Your watch should confirm with "Restore processing."


The smart watch will restart and the settings will be restored to the default settings. It will leave you at the home screen.

# POWER SAVE



Press the Power Save Icon on your home screen to set or turn off Power Save mode.

Power Save mode will attempt to put your watch on standby as much as possible to conserve battery life.



If Power Save is turned on, the watch will automatically attempt to conserve battery life.

It will override any settings you have entered in the "Display" menu of your Settings.

Once Power Save is selected, your watch will show that your selection is "Done."

Your watch will take you back to your App menu screen.

# RINGTONE




Press the Ringtone Icon on your home screen to set your ring, or alarm notifications.


Select a ringtone preset to customize how your watch should act when alerting you of notifications.  
Select activate to set the selected preset.




Select "Customize" to adjust preferences of this preset.



Select "Alert type" to choose how your watch should act when alerting you of notifications.




Select "Ring type" to choose how your watch should ring.



Scroll down on the touch screen of your watch to select your preferred "Ringtone."

The smart watch comes pre-programmed with 5 ringtones to choose from. Scroll down to see all 5 options.




Once you select a ringtone, it will appear under "Ringtone."

To preview the other ringtones, click back into the "Ringtone" list and select another ringtone. Wait 2 seconds, and your watch will play a preview of that ringtone.

Scroll down on the touch screen of your watch to select your preferred "Ringtone volume."

On the next screen, use the "-" or "+" buttons on your touch screen to adjust volume.



These buttons will control the volume of your ringtone under this preset. You must "Activate" this preset in order for it to take effect.



When your Ringtone settings are set to your preferences, press the "Confirm" button on your watch frame. A pop up menu will show.


Select change if you wish to go back and change these settings. Select save if you wish to save these settings and return to the ringtone menu.

To change or set other presets, re-peat the aforementioned steps for desired preset.

# ALARM




Press the **Alarm Icon** on your home screen to set an alarm. Your smart watch can set up to 5 customizable alarms.




Select any alarm time without a check mark next to it to customize alarm settings.

Scroll down on the touch screen of the watch to access the 5th alarm.



Use the left and right arrow keys to turn the alarm on or off.

Press into the time display to set the time of your alarm.



A dial will appear to let you indicate the current date. Press the field you wish to edit and then press the plus or minus symbols to increase or decrease the number.

Press "OK" to confirm you alarm time or press "Back" to exit without saving the time.

Scroll down on the touch screen of the watch to continue customizing alarm settings.




Select the box under "Repeat" to choose the days you want your alarm to ring.




"Once" will have your alarm ring only once your watch clock reaches the set alarm time.



"Everyday" will have your alarm ring daily once your watch clock reaches the set alarm time.



"Custom" allows you to choose which days of the week you want your alarm to ring.




Select the day of the week you would like your alarm to ring.




A pop-up window will appear to allow you to select "On" or "Off."

Once you have made your selection, press "Done."







A check mark will appear next to the days of the week you have set your alarm to ring.

Scroll down on this screen to access and customize all 7 days of the week.


Press the "Return" key on the watch frame to return to your Alarm menu. Scroll down on the touch screen of the watch to continue customizing alarm settings.

Select the box under "Alarm tone" to choose your alarm noise. These Alarm tones will match your 5 preset ringtone choices. Scroll down to access the 5th ringtone.



Press the "Confirm" button on the frame of your smart watch once you have confirmed your alarm details.

Your alarm will appear in the list of alarms with a check mark next to it, indicating that details have been set and the alarm is on.



To set additional alarms, select another alarm time from the list.

Follow all steps to set each alarm as shown in this section.

When you have finished setting all desired alarms, press the "Return" key on your smart watch frame to return to the App menu screen.



# CALENDAR



Press the Calendar Icon on your home screen to access your calendar.



The Calendar will immediately bring you to today's date, highlighted in light blue.

Use the left and right arrows on the top of the calendar to scroll to the previous or the following months.



Press the "Confirm" key on the smart watch frame to either jump back to today's present date after scrolling, or to jump to a specific date.



Press "Jump to date" in order to input a specific date you want to see on the calendar.

Press into the date display. A dial will appear to let you indicate the date you wish to look at.



Please type according to the below format: YEAR.MO.DA

Press the field you wish to edit and then press the plus or minus to increase or decrease the number.

Press "OK" to have your calendar jump to the date you input. Press "Back" to exit without saving the date.




When you are done using your Calendar, press the "Return" button on your watch frame to return to your App menu screen.

# PEDOMETER



Press the Pedometer Icon on your home screen to access your pedometer.



Your Pedometer has a built-in timer and step counter.

Press "Start" to start the timer and the step counter.

You can press "Back" if you have not started the timer, and you want to return to your App menu screen.



You can also "Pause" and "Resume" the timer.

If you want to reset the timer and your step counter, press the "Reset" button.

The built-in sensor on your smart watch will track your movements and count your steps.

Swipe right on your screen to check your summary page on the second screen. The red dot on the bottom of your Pedometer App will show you which screen you are on.

Your summary page will show the below information:

Step: 0  
Time: 0 m 0 S  
Fat: 0.000000g  
Heat: 0.000000  
Speed: 0.000000  
Mileage: 0.000000

Step: Total number of steps  
Time: Duration of timer  
Fat: Grams of fat burned  
Heat: Heat index advisor (°F)  
Speed: Walking speed  
Mileage: Total traveled distance



If you have reset your Pedometer timer and step counter, you can press "Back" to return to your App menu screen.





When you are finished using your Pedometer, press the "Return" key on the watch frame to return to your App menu screen.

# STOPWATCH



Press the Stopwatch Icon on your home screen to access your stopwatch.



Press the left button to start your stopwatch.



Press it again to click your stopwatch. The stopwatch will keep going, but the time will freeze for you to read it.

Press the right button to reset your stopwatch.




When you are finished using your Stopwatch, press the "Return" key on the watch frame to return to your App menu screen.

# CALLS




Press the **Calls** icon on your home screen to access your call history.

Your smart watch will sync with your mobile device to show you a list of Missed calls, Dialed calls, Received calls, or all full list of All calls.






Select the list you would like to access. Each list will provide you a list of corresponding calls.

Select an entry on the list to see call details and contact information for the caller.



Scroll down to read all call info. Press the "Return" button to return to your Call history menu.



When you are finished checking your Call history, press the "Return" key on the watch frame to return to your App menu screen.




# BT MUSIC



Press the BT music icon on your home screen to play music from your smart watch.

Your smart watch will connect to your smart phone or tablet that is playing music. Once it is connected, you can control media from the screen below.



1. Track Name
2. Elapsed Time
3. Remaining Time
4. Lower Volume
5. Increase Volume
6. Previous Track
7. Play/Pause
8. Next Track



When you are finished using your BT music speaker on your smart watch, press the "Return" key on the watch frame to return to your App menu screen.

# CALCULATOR



Press the **Calculator** icon on your home screen to access your calculator.

A numeric keypad will appear.  
Enter in your desired calculation and press the "=" button to calculate the result.



Press "Clear" to clear your entry.

You can press "Back" to return to your App menu screen.




When you are done using your calculator, you can also press the "Return" button on your watch frame to return to your App menu screen.

# SLEEP MONITOR




Press the **Sleep Monitor** Icon on your home screen to monitor your sleep.

A timer will appear. Press "Start" when you are ready to sleep.



You can press "Back" if you have not started the timer, and you want to return to your App menu screen.

You can also "Pause" and "Resume" the timer.



If you want to reset the sleep timer, press the "Reset" button.

Each time you wake, the "Results" section will note if your sleep habits are good and uninterrupted or bad and constantly interrupted.



If you have reset your Sleep Monitor timer, you can press “Back” to return to your App menu screen.




When you are finished using your Sleep Monitor, press the “Return” key on the watch frame to return to your App menu screen.

# PHONE BOOK




Press the Phonebook icon on your home screen to access your contacts list.

Please note, you will need to disconnect from "BT music" before your smart watch can access your contacts list. If your smart watch asks you to disconnect, press the Confirm button on the watch frame before proceeding.



Your Phonebook will connect to your phone and show you your contacts list.

The first number is your number. Press it to view details.



Your contact will always be named "My number." Your mobile number is listed below.

Press the "Return" key on your watch frame to go back to your contacts list.



Contacts will be listed in alphabetical order based on first name.

Select any name on the list whose contact you want to view, or who you want to call.


You can scroll through your contacts by scrolling directly on the touch screen of your watch to find a specific contact.

In this example, Dawn is selected.



An example of a full contact is shown to the left.

To call your selected contact, select the mobile number.



A pop-up window will appear. Select "Call."

To cancel, press the "Return" key on your watch frame to go back to the contact page.

Your smart phone will indicate it has begun dialing the selected contact.

Below is a helpful diagram of available buttons and functions to use during a call.



1. Contact Name
2. Call Status / Duration
3. End Call
4. Numeric Keypad
5. Audio Source
6. Mute
7. Settings
8. Volume
9. Contacts List

NOTE: The numeric keypad and settings are not available until after a call has been connected.

After the call is connected, you can access a numeric keypad. This is useful if you are on a call that requires you to make numeric selections.

Press the "Numeric Keypad" button and a keypad will appear. Press your desired selection or enter information.




When you are done, press the "Return" key on your smart watch frame to return to your call.


You can select the audio source for your call.

Pressing the "Audio Source" button will switch the call from your smart watch speaker to your smart phone.

Press again to switch back to the source indicated on the icon.




Switch to Smart Watch Speaker




Switch to smart phone

During a call, you can mute/unmute a call by pressing the "Mute" button as shown below.



Mute call




Unmute call




During a call, you can adjust call settings.  
Press the "Settings" button and a scrolling pop-up screen will appear with the following options.

Scroll to down to see all 5 options. Their functions are listed below.



- Hold - Places the call on hold, or takes a call off hold
- DTMF - (Dual Tone Multi-frequency) Brings up the numeric keypad
- Mute - Mutes / unmute the call
- End single call - Ends the call
- Switch audio path - Switches audio from your watch to smart phone

Press the "Volume" button to adjust the call volume.




Press the "Contacts List" button to access or your contacts list.



At any time while using any of these functions, if you want to return to your call, you can press the "Return" key on the watch frame to return to your call.

Press the "End Call" button the end a call.

Your watch will bring you back to your contact's info page.



When you are done using your Phonebook, press the "Return" button on your watch frame to return to your App menu screen.

# DIALER



Press the Dialer Icon on your home screen to dial numbers from a phone keypad.

A numeric dial-pad will appear.

Enter the number you wish to dial including 1 + area code.



Press the "Return" button on your watch frame to delete any mis-entered numbers.

Press the "Confirm" button on your watch frame to dial the number.

Please refer to the "Phonebook" section for details about making calls from your smart watch.



When you are done using the Dialer, press the "Return" button on your watch frame to return to your App menu screen.

# BT CAMERA



Press the BT camera icon on your home screen to access the remote shutter button.

BT notice  
"Please  
install "BT  
Notice" app  
in remote device

This App can **only** be used on smart watches paired with Android devices.

Before using, please download the "Fundo Companion" App. See "Settings / QR Code" for installation details.



The BT camera **will** connect to your Android device's built-in camera and work as a remote shutter button.

You can see a low-resolution preview of your phone's camera.

When switching from portrait to **landscape**, give your smart watch a couple seconds to sync the image preview before taking a photo.

Press the "Confirm" button on your watch frame to take a photo.  
Wait for your smart watch to finish taking the photo.

The photo preview will freeze on your watch screen. The photo will also save to your Android's camera roll.



Press the "Return" button on your watch frame to return to your camera preview to take another photo.

NOTE: BT camera only accesses the outward facing camera of your Android device. It will not allow you to flip your camera to face yourself to take selfies.



When you are done using the BT Camera shutter button, press the "Return" button on your watch frame to return to your App menu screen.

# ANTI-LOST



Press the Anti-Lost Icon on your home screen to use the watch and phone tracking feature.



Some features of this App can only be used on smart watches paired with Android devices. Please see each sub-section for compatibility before proceeding.

## ANTI-LOST Looking Phone



Before using this first feature, please download the "Fundo Companion" App. See "Settings / QR Code" for installation details.

Press on "Looking Phone."  
Your smart watch will remind you to install "BT Notice" on your Android.



Use "Looking phone" if you want your Smart Watch to locate your Android device.

It will send a push notification using the "Fundo Companion" App on your Android to have your phone ring.



Once your Android is located, you can press the "Return" button on your smart watch frame to return to the previous screen.

On your Android device, you can open the "Fundo Companion" App and have the App locate your smart watch.



Press the 3 lines next to "Home" in the top left corner for the side bar menu to display.

Press "Looking for device" to have your Android locate your smart watch. Your smart watch will ring for you to locate it.



Your Fundo Companion App on your phone will ask you if you found your smart watch.

Press "OK" once you have found your smart watch.



Press on "Anti-lost" to set a notification for when your Smart Watch is out of range of your Apple or Android smart phone or tablet.



You have the option to turn this alert On or Off.

Use the left and right arrows to set this alert.





Press the "Confirm" key on the smart watch frame to set your alert.

If you are wearing your Smart Watch and move further than 33 ft (10m) away from your paired device, your smart watch will alert you with your set Anti-lost alert.



Press the "Confirm" key to keep sounding the Anti-lost alert until you find your phone.




Press the "Return" key to stop the Anti-lost alert because you have located your phone.

# SEDENTARY REMINDER




Press the Sedentary Reminder icon on your home screen to set a reminder not to stay seated for too long.



Use the left and right arrow keys to turn the reminder on or off.

Press into the time display to set the time of your reminder. A dial will appear to let you indicate the number of minutes you want to wait until your smart watch's reminder rings.




Press the plus or minus symbol to increase or decrease the number.

Press "OK" to confirm the time, press "Back" to exit without saving the time.



Press the "Confirm" key on the smart watch frame to set your reminder.

Press "Save" from the pop-up menu, or "Cancel" to cancel your reminder.




# DRINK WATER REMINDER



Press the Drink Water Reminder Icon on your home screen to set a reminder to drink water consistently throughout the day.




Once the app is open and the water drop icon shows, use your finger to swipe from right to left on the screen to access the reminder presets.



Select any reminder time to customize reminder settings.


If the icon shows a white border, that indicates the alarm is already set.

Scroll down on the touch screen of the watch to access the next 4 alarms.



Use the left and right arrow keys to turn the alarm on or off.

Press into the time display to set the time of your alarm.




A dial will appear to let you indicate the current date. Press the field you wish to edit and then press the plus or minus symbols to increase or decrease the number.

Press "OK" to confirm you alarm time or press "Back" to exit without saving the time.

Scroll down on the touch screen of the watch to continue customizing alarm settings.




Select the box under "Repeat" to choose the days you want your alarm to ring.




"Once" will have your alarm ring only once your watch clock reaches the set alarm time.



"Everyday" will have your alarm ring daily once your watch clock reaches the set alarm time.





"Custom" allows you to choose which days of the week you want your alarm to ring.



Select the day of the week you would like your alarm to ring.

A pop-up window will appear to allow you to select "On" or "Off."

Once you have made your selection, press "Done."



A check mark will appear next to the days of the week you have set your alarm to ring.

Scroll down on this screen to access and customize all 7 days of the week.


Press the "Return" key on the watch frame to return to your Alarm menu. Scroll down on the touch screen of the watch to continue customizing alarm settings.

Select the box under "Alarm tone" to choose your alarm noise. These Alarm tones will match your 5 preset ringtone choices. Scroll down to access the 5th ringtone.



Press the "Confirm" key on the smart watch frame to set your reminder.

Press "Save" from the pop-up menu, or "Cancel" to cancel your reminder.



# BATTERY CARE

The lithium-ion battery is built into the device. Do not disassemble the device to remove the battery or attempt to separate it from the device.

- When charging the device, please use the enclosed USB charging cable or otherwise ensure that the battery charging conditions are met.
- Do not connect or attach the device or the battery to a power supply plug or directly to a car's cigarette lighter.
- Do not place the device or batteries near a fire, or into direct sunlight. Heating the device and/or the battery can cause additional heating, breaking, or ignition of the battery inside the device.
- Do not continue charging the battery if it does not recharge within the specified charging time. Doing so may cause the battery to become hot, rupture, or ignite.

To preserve natural resources, please recycle or dispose of batteries properly. This product contains lithium-ion batteries. Local, state, or federal laws may prohibit disposal of lithium-ion batteries in ordinary trash. Consult your local waste authority for information regarding available recycling and/or disposal options.

- Do not attempt to modify, change, or replace your battery.
- Do not use your device if the battery begins to emit odor, overheats, or begins to leak.
- Do not touch any leaking materials or breathe fumes emitted.
- Do not allow children and animals to touch an exposed battery.
- The battery contains dangerous substances, do not open the battery, or insert anything into an exposed battery.



- Please only use the charger provided by Hype®.
- Do not attempt to charge the device if the battery has discharge or emits any substances. In that case, immediately distance yourself from the battery in case of fire or explosion.
- Lithium-ion batteries are considered to be hazardous materials. Please follow all local, state and federal laws in regards to recycling, handling and disposing of Lithium-ion batteries.

## SPECIFICATIONS

Bluetooth:	Version 3.0
Display:	1.44 Inch LCD touch screen (3.65 cm)
Resolution:	128 x 128pixels
Charge Time:	Up to 1.5 Hour
Battery:	Built-in 180 mAh Lithium-ion Battery
Talk Time:	Up to 45 Minutes
Standby Time:	Up to 120 Hours
Charging Interface:	Micro USB
Weight:	1.4 oz (0.0398 kg)

FCC ID: 2AANZWTCBHT  
BT ID: D031981

# FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## WARRANTY INFORMATION

The condition of this warranty and our responsibilities under this warranty are as follows:

Supplier's warranty is non-transferable. And this warranty is limited to the original purchaser only.

\* You must be able to prove the date of original purchase of the unit with a dated receipt.

\* The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.

\* The responsibility of supplier's products shall be limited to the repair or replacement of the product as its sole discretion.

\* Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorations and other accessories.

\* A supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassembly.

\* Modification and repair of the unit should be done by authorized and qualified service personnel, Center or returned to the manufacturer.

\* This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual warranty obligations.

We offer a warranty on our products in accordance with the following conditions:

1) DGL™ products are covered by a 3 month warranty. We will resolve damages or defects on DGL™ products free of charge within 3 months of the purchase date under the following warranty conditions. For any damage or defect determined later than 3 months after the purchase date, proof of a manufacturing fault must be submitted for repair under warranty.

2) The warranty does not cover batteries and other parts, which

are considered consumables, parts that break easily such as glass or plastic or defects based on normal wear and tear. There is no warranty obligation in the event of marginal differences compared to the target appearance and workmanship provided these have a negligible effect on the product's fitness for use, in the event of damage caused by chemical or electrochemical effects, by water or generally from abnormal conditions.

3) The warranty will be performed in such a way that we shall decide whether to repair the defective parts or to replace them with working parts free of charge. DGL™ reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or at a reasonable cost. Requests cannot be made for repairs to be carried out on site. Parts that have been replaced or exchanged become our property.

4) The warranty claim does not apply if repairs or other work is carried out by unauthorized persons or if our products are equipped with additional parts or accessories that are not approved for our product.

5) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts installed ends with the warranty period for the entire product.

6) Any other further claims are excluded, especially those for replacement due to damage caused to the outside of the product, provided there is no obligatory legal liability. We therefore accept no liability for accidental, indirect or other consequential damage of any kind, which leads to usage restrictions, data loss, and loss of earnings or interruption to business.

Asserting a warranty claim:

1) To make use of the warranty service for hardware issues, you must contact the DGL™ Service Center by email at [support@dglusa.com](mailto:support@dglusa.com).

2) DGL™ will try to diagnose and solve your problem. If it is

determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to DGL™.

**IMPORTANT:** DGL™ will only accept parcels that have an RMA number.

Please observe the following when sending the product:

- 1) Send the product suitably packaged with carriage and insurance paid. Do not enclose any accessories with the product (cables, chargers, manuals, etc.) unless the DGL Service Center specifies otherwise.
- 2) Mark the RMA number on the outside of the package in such a way that it is visible and clearly legible.
- 3) You must enclose a copy of the sales slip as proof of purchase.
- 4) Once DGL™ has received the product, it will meet its warranty obligations in accordance with the warranty conditions and will return the product to the sender with carriage and insurance paid.

### **SERVICE OUTSIDE OF WARRANTY**

DGL™ can refuse any service claim made that is not covered by the warranty.

If DGL™ agrees to provide a service outside the warranty, the customer will be invoiced for all repair and transport costs. DGL™ will not accept any packages that have not first been approved by DGL™ by means of an RMA (Return Material Authorization).

DGL Group guarantees the quality of this product.

For questions or comments, please feel free to contact us via email at [support@dglusa.com](mailto:support@dglusa.com).

**To download a digital copy of this manual, please visit us at [www.dglusa.com/smartwatch](http://www.dglusa.com/smartwatch)**